

Installation Instructions for Stevensons-Stone® Fire Surrounds

1. Unwrap the fire surround taking care not to cut through the bubble wrap with a sharp instrument and damaging the Stevensons-Stone® fire surround.
2. Locate the steel dowels into the big head fixings on the reverse of the fire surround.
3. Mark up the location of the dowels where they connect with the wall.
4. In normal circumstances the dowel should be inserted approximately 100mm into the wall. The dowels provided will need to be cut accordingly.
5. Once you have established the location on the wall for the dowel a minimum hole size of 12mm diameter should be formed in the wall for each of the dowel fixings.
6. Once the hole has been drilled it should be cleared of any dust or debris.
7. Firmly secure the cut dowels into the big head fixings on the reverse of the fire surround.
8. Using a mastic gun and sikaflex adhesive fill the hole with the adhesive.
9. Carefully lift the fire surround into position lining the dowels to the holes. Gently push into position.
10. The fire surround will need to be secured in this position whilst the adhesive cures. Ideally for at least a 24 hour period.

Notes

- Appropriate safety wear should be worn during installation.
- We suggest the above fixing operation is carried out by a team of 2.
- The installation should be carried out by persons with appropriate knowledge / experience.
- These instructions are applicable to a solid wall background only. For backgrounds other than solid walls contact us for further advice.